
### **Estate**<sup>®</sup>

### **TOP AND CABINET PARTS**


AUTOMATIC WASHER



### **TOP AND CABINET PARTS**

Illus. No.	Part No.	DESCRIPTION
1	LIT3956025	Literature Parts Installation Instructions
	LIT3955914 LIT3955873 LIT3956344 LIT8542052	Feature Sheet Use & Care Guide Energy Guide Wiring Diagram
2 3	8271378 62750	Top Spacer, Cabinet To Top (4)
4 5 6	357213 63424 62780	Nut, Push-In (2)
7 8	3357011 3356311	Screw, 10–16 x 1/2 Screw & Washer, Lid Switch (2)
11 13	3949237 3351355	Switch, Lid Screw, Lid Hinge Mounting (4)
15 16 17 18	54584 91770 19119 21258	Hinge, Lid (L.H.) Hinge, Lid (R.H.) Bumper, Lid Hinge Bearing, Lid Hinge (2)
19 20 22 28	3954489 358684 9724509 3390631	Lid Strike, Lid Switch Bumper, Lid (2) Screw,
31 32	90016 3362952	10–16 x 3/8 (5) Clip, Harness Dispenser, Bleach

### **CONTROLS AND REAR PANEL PARTS**



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROLS AND REAR PANEL PARTS For Model: TAWS800JQ2

(Designer White)

Illus.	Part		Illus.	Part		Illus.	Part	
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
1	3976300	Washer, Water	10	8055003	Clip, Harness	28	3366912	Clamp, Hose
		Inlet Hose (4)			& Pressure Hose	29		Capacitor,
		(1–1/16 x 5/8)	11	3351614	Screw, Ground			Motor Start
2	9740848	Screw	12	3366846	Switch, Water Level	30		Clamp, Hose
3		Hose, Water	13	3948608	Bracket, Control	31	8317496	Clamp, Hose
		Inlet (2)	14	661661	Cord, Power	32		Hose, Pump To Tub
		Blue Coupler			(Includes Item 15)	33		Shield, Capacitor
		Red Coupler	15	3952821	Strain Relief,	34		Retainer, Harness
4	3357027	Nozzle-Drain			Power Cord	35	661614	Switch, Water
		Hose	16		Cap, End (L.H.)			Temperature
5		Strap, Console (2)	17		Screw, Ground	36	3400818	Screw, Timer
6		Panel, Rear	18	3952164	Valve, Water			Mounting
7		Pad, Rear Panel			Mixing	39		Panel, Console
8	3951609	Hose, Drain	19		Clamp, Hose	44		Knob, Timer
		(4 ft.)	20		Clip, Capacitor	45		Dial, Timer
	661577	Hose, Drain	21		Clamp, Hose	47		Knob, Control
		(9 ft.)	22	3357328	Hose, Vacuum	49	388326	Screw, 8-18 x 1.25
		(Not Included)			Break			(Panel to Top)
	3357090	Extension,	23		Clamp, Hose	50		Screw, 10-16 x 3/8
		Drain Hose	24		Break, Vacuum	51		Cap, End (R.H.)
		(21 Inches.)	25		Edge Protector	55		Clip, Harness
		(Not Included.)	26	8317940	Hose-Corrugated	56	3366913	Clamp, Drain
9	8542050				Assembly			Hose
		(60 Hz.)	27	90767	Screw, 8-18 x 3/8	59		Shield, Suds
		(Motor Not A				60	3956518	Harness, Wiring
		Service Part)						(For Detail See
								Page 9 & 10)

### **AGITATOR, BASKET AND TUB PARTS**

# AGITATOR, BASKET AND TUB PARTS For Model: TAWS800JQ2

(Designer White)

Illus. No.	Part No.	DESCRIPTION
1	63580	Dispenser
1 2 3 5 6	358237	Screw & Washer
3	3348752	Mover, Clothes
5	3347288	Agitator
6	8528150	Tub Ring
7	3976308	
8	21366	
9	8526016	Basket &
40	0540700	Balance Ring
10 11	8519788	3
12	63849 3363661	Tub Bearing–Driven
12	3303001	Cam
13	389140	
14	383727	
15	3347780	
		Switch
16	3348117	Agitator
		(Complete)
17	3949550	Washer
18	3366877	Dog, Agitator
		Clutch (4)
20	3354733	Barrier, Cap
21	3348855	Seal, Inner Cap
22 23	3363663 3350389	Cam Driven
23 24	3354845	Spacer, Thrust Clip, Agitator
24 25	3355921	Washer, Agitator
23	0000021	Washer, Agitator


# BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS For Model: TAWS800JQ2

(Designer White)


		(I	Designer White)			
<b>(5)</b>	IIIus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
	1	388952	Brake & Drive Tube (Complete) (Refer to Page 11 For Further	10 11		Screw, Gearcase To Base (3) Plate, Motor Mount To
1 2 3 4 5 5 5 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6	2 3 4 5 6 7 8 9	62697 63283 3951311 3951308 62646 3946792	Breakdown) Washer, Spin Tube Thrust Ring, Spin Tube Support Ring, Retainer Clutch (Complete) Band & Lining, Clutch (Includes Illus. 7 & 8) Cap, Clutch Spring (2) Spring, Clutch Gearcase (Complete) (Refer To Page 12 For Further Breakdown)	12 13 14 15 16 17 18 19 20 21 22 23	285753 3946532 3355454 3400516 3349637 3362089 8528157 3952056 62700	Anti-Rattle Screw Retainer, Motor (2) Shield, Tub To Motor Motor, Main Drive Switch, Main Drive Motor Retainer, Pump (2) Pump (Complete)
9 10 11/12 13 14	16		17 23		20	

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

#### **MACHINE BASE PARTS**



# WIRING HARNESS PARTS For Model: TAWS800JQ2 (Designer White)



WH2G

#### **WIRING HARNESS PARTS**


For Model: TAWS800JQ2 (Designer White)

Illus.	Part		Illus.	Part		Illus.	Part	
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
1 2 3 4	388498 3347812	Clip, Harness Clip, Harness Clip, Harness Clip, Harness	13	3348075	Block, Disconnect (Motor 3 Speed) (Use Term. 94613 Or 94614.)	23 24 25	60687	Connector, Etc Connector, Relay (Use Term.308569) E.T.C. Control
5		Clip, Harness	14	3347243	Block, Disconnect	26	3948617	Connector (T.P.A.)
6 7	389379	(Suds Models)	15 16		(Use Term. 352088) Protector Connector			(3-Circuit) (Lid Switch) (Use Term. 3948619
8	352090	Timer, Block Disconnect (White)	17	387566	(2-Way) (Use Term.94614) Plug, Terminal	27	3360056	OR 3948620.) Connector (T.P.A) (3–Circuit)
9	352089	Timer, Block Disconnect (Black)			(4-Way) (Power Cord) (Use M3 Screws)			(Pressure Switch) (Use Term.3948619 OR 3948620.)
10	62889	Receptacle, Terminal (3–Way) (Lid Switch) (Use Term.94613)	18 19	3390423	Clip, Harness Block, Disconnect (12–Way) (Timer) (Use Term. 94613)	28 29	3354925 3354926	Block, Connector (Cold Valve) (Use Term.693217) Block, Connector (Hot Valve)
11	353424	Or 94614.) Plug, Terminal (3–Way) (Power Cord) (Use Term.94613)	20	3347730 388818	Receptacle (6–Way) (Use Term. 94613) Plug, Terminal (12–Way)	30	3948615	(Use Term.693217) Connector (T.P.A.) (6-Circuit) (Temp. Switch) (Use Term.3948619
12	62505	Block, Disconnect (Motor 2 Speed) (Use Term.352088)	22	3369366	(Use Term. 94613 Or 94614.) Timer, Block Disconnect (Black) (Amp) (Use Term.3369365)			OR 3948620.)

# FOR COMPLETE WIRING HARNESS REFER TO CONTROL AND REAR PANEL PARTS PAGE

### **BRAKE AND DRIVE TUBE PARTS**

For Model: TAWS800JQ2 (Designer White)



Illus. No.	Part No.	DESCRIPTION				
1	388952	Brake And Drive Tube (Complete)				
2	62658	Ring, Thrust				
2 3 4 5	91939	Seal, Oil				
4	356427	Seal, Drive Tube				
5	356937	Spacer, Drive				
		Tube				
6	64027	Tube, Basket				
		Drive (Includes				
_		Illus. 3, 4, 5 & 9)				
7	64035	Ring, Retaining				
8	64232	Shoe, Brake				
9	62703	"T" Bearing,				
10	62648	Spin Tube				
10	02040	Cap, Brake Spring (2)				
11	387806	Spring (2) Spring, Brake				
12	62909	Sleeve, Brake				
	02000	Spring				
13	63023	Cam, Brake				
		Release				
14	63022	Sleeve, Cam				
15	64194	Driver, Brake				
		Cam				
16	90368	Ring, Retaining				
FOLLOWING PARTS						

## FOLLOWING PARTS NOT ILLUSTRATED

285208 Lubricant (Use Only In Brake Shoe Assembly On Roller & Pin)


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


### **GEARCASE PARTS**

			4	
	;		1	
	$\sim$ 1 .22 $\stackrel{\cdot}{}$			
2		Illus.	Part	
		No.	No.	DESCRIPTION
3		110.	110.	DECORM HOR
		4	3360630	Gearcase
<u> </u>		1	3300030	(Complete)
5	23	2	285202	Cover, Gearcase
! <u>\</u>   6		3	3349985	Seal, Gearcase
. 1	7 24	4	285195	Cover Sealer, Gasket
·		•		(.20 Fl. Oz.) (6 ml)
	- CF	5	63320	Pinion, Spin
8	25	6	356427	(Includes Illus. 25) Seal, Spin
. 9	26	Ü	000427	Pinion
		7	389387	Shaft, Agitator
10		8	90369	(Complete)
1 9		9	62677	Ring, Retaining (2) Retainer, Spring
		10	62676	Spring, Agitate
		11	63273	Gear, Agitate
1 12		12	62619	(Includes 15 and 29) Washer, Agitate
13	' '			Gear
		13	62580	Cam Follower
14		14	62581	(Includes 14) Cam, Agitate
'				(Includes 13)
·		15	285509	Shaft, Agitator (Includes 11 and 29)
1		16	62618	Washer, Cam Thrust
		17	16018	Bearing, Thrust
i ĝ		18	85529	Ball, Bearing
		19	389230	Bottom and Pinion, Gearcase
15	27	21	285352	Seal, Thrust Plug
		22	3351614	Screw, Gearcase
				Cover, Mounting (8) (10–24 x 3/8)
ı	9 28	23	3362552	Ring, Retaining
29		24	285735	Washer Kit,
		25	62570	Thrust Gear, Spin
1 8		26	388253	Neutral Assembly
17		27	3349296	Rack, Connecting
110		28 29	62621 388815	Actuator, Shift Washer,
18	<b>19</b>	29	300013	Intermediate
	nu			ouid
21				
	4			
	GC _ 215 _ C			
L				

### **WATER SYSTEM PARTS**

For Model: TAWS800JQ2 (Designer White)






WS400

Illus. No.	Part No.	DESCRIPTION
1	285442	Connector Kit, Plastic Drain
2	285321	Hose Sleeve Kit, (Contains 2 Sleeves)
3	370447	Clamp, Hose
4	16272	Connector,
5	285320	Straight Siphon Break Kit
6 7	65349 367031	(Not Included) Clamp, Hose Drain Protector (Not Included)

### **MISCELLANEOUS PARTS**

For Model: TAWS800JQ2 (Designer White)



Illus. No.	Part No.	DESCRIPTION
1	3976263	Miscellaneous
2	3976300	Parts Bag Washer, Inlet Hose
3	3366912	(1-1/16 x 5/8) (4) Clamp, Hose
4		Nut, Lock (2) (3/8–16)
5	389102	Foot, Front (2)
6	3366913	Clamp, Hose

## **OPTIONAL PARTS (NOT INCLUDED)**

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
PAINT	, TOUC	H-UP (1/2oz.)	OIL			SEAL	.ER	
	72017	White		350572	Oil, Gearcase (16 Oz.)		285195	Sealer, Gasket
PAINT	, PRES	SURIZED SPRAY			(10 02.)			(.20 Fl. Oz.) (6 ml)
(12 oz	<u>.)</u>		LUBF	RICANT		ACCI	SSOR	Y PARTS
	350938 350930	Primer, Gray White		285208	Lubricant (Use Only in Brake			Drain Protector Siphon Break Kit
PAINT	, BULK	(1 qt.)			Shoe Assembly On Roller and			
	799344	White (Uncut)			Pin)			